

Automatic Scrubber Maintenance

DAILY MAINTENANCE (After Every Use)

1. Drain and rinse out the recovery tank.
2. Remove and clean the float shut-off screen located in the recovery tank.
3. Drain the solution tank and rinse out the inside with hot water, 60°C maximum temperature, as needed.
4. Remove the pad/brush and clean. Rotate pad or replace when worn.
5. Wipe the squeegee blades clean. Store the squeegee assembly in the raised position to prevent blade damage.
6. Check the condition of the squeegee blade wiping edge. Rotate blade if worn.
7. Clean the machine with an all- purpose cleaner and damp cloth.

FOR SAFETY: When cleaning machine, do not power spray or hose off machine. Electrical malfunction may occur.

8. Inspect the condition of the scrub head skirt, replace if worn or damaged.
9. Recharge the batteries. To prolong the life of the batteries, only recharge the batteries if machine was used for a total of 30 minutes or more.

MONTHLY MAINTENANCE

1. Remove the solution tank filter from underneath the machine and rinse out the screen. Make sure the solution tank is empty before removing filter.
2. Clean the battery tops to prevent corrosion.
3. Check for loose battery cable connections.
4. Inspect and clean the recovery tank cover seal. Replace if damaged.
5. Lubricate all pivot points and rollers with a water resistant grease.
6. If equipped, clean the parking brake clamp with a cleaning solvent.
7. Check the machine for loose nuts and bolts.
8. Check the machine for leaks.